


## FIXING INSTRUCTIONS

### TWIST AND LOCK SOFFIT VENTILATOR – SV200



#### RECOMMENDED TOOLS FOR INSTALLATION

The following hole cutting saws, which are attached to the drill, with a Standard No 2 Arbor:

- Hardened steel for timber soffits
- Carbide tipped for asbestos type soffits
- Diamond tipped for heavy duty contact use

1. Fit the Soffit Ventilator at 200mm centres and centrally along the soffit board to achieve 10,000mm<sup>2</sup>/m.
2. To provide continuity of airflow into the roofspace, use Glidevale Roof Ventilators, which are available for either new building or refurbishment.
3. Cut the 70mm holes in the soffit board at 200mm centres using the recommended hole saw.
4. Using the recommended Glidevale installation tool, insert the ventilator into the prepared hole with a half turn in a clockwise direction whilst applying upward pressure.

**FOR FURTHER INFORMATION ON ALL GLIDEVALE PRODUCTS PLEASE CONTACT:**

.....

#### GLIDEVALE LIMITED

2 Brooklands Road, Sale, Cheshire, M33 3SS

Telephone: (+44) 0161 905 5700 Fax: (+44) 0161 905 2085 Web: [www.glidevale.com](http://www.glidevale.com) Email: [info@glidevale.com](mailto:info@glidevale.com)

#### BPD

A Member of the Building Product Design Group